

SAFETY INSTRUCTIONS


3-0055-0P01 FLEXCARD PMC II





Eberspächer Electronics
GmbH & Co. KG
Robert-Bosch-Str. 6
D-73037 Göppingen

Telefon (zentral)
+ 49 7161 9559-0

www.eberspaecher.com

	⚠ WARNING
	<p>MAINS VOLTAGE UP TO 110 / 230 VAC AT THE COMPUTER CHASSIS:</p> <p>ELECTRICAL SHOCK HAZARD!</p> <p>TO PREVENT DEATH, PERSONAL INJURY OR DAMAGE:</p> <p>DISCONNECT THE POWER CABLE OF THE COMPUTER BEFORE OPENING THE CHASSIS.</p>

	⚠ CAUTION
	<p>INAPPROPRIATE USE:</p> <p>PERSONAL INJURY OR DAMAGE TO PROPERTY POSSIBLE!</p> <p>READ THE INSTRUCTIONS FOR USE PRIOR TO USE AND FOLLOW THE INSTRUCTIONS CAREFULLY. FOR SAFETY AND WARRANTY REASONS, DO NOT CHANGE OR MODIFY THE PRODUCT.</p>

	NOTICE
	<p>Electrostatic sensitive product:</p> <p>Performance degradation or loss of functionality hazard!</p> <p>Take proper ESD precautions when handling the product. Refer to instructions for use, Appendix A for relevant safety information.</p>

This product is NOT designed, intended, or authorized for

- use as part of medical systems,
- life support applications,
- aviation, space, nuclear or military applications,
- use in areas where combustible or explosive gas mixtures are likely to occur,
- other applications in which a mistake or malfunction may result in death, personal injury or severe physical damage.